



DA 2450, DA 2558, DA 2558 EXTA, DA 2578, DA 2578 EXTA, DA 2518

de - Abluftanschluss versetzen. Der Umbau erfolgt vor der Montage.

en - Repositioning the ducting. Repositioning is carried out before installing the cooker hood.

fr - Déplacement du raccordement d'évacuation. Il faut procéder aux modifications avant le montage.

it - Modificare la conduttrice evacuazione aria. Effettuare la modifica prima dell'installazione.

es - Cambiar la conexión de salida de aire. El cambio se realiza antes del montaje.

nl - Luchtafvoeraansluiting verplaatsen. De ombouw moet vóór de montage gebeuren.

da - Udluftningstilslutning flyttes. Ombygningen skal foretages før monteringen.

fi - Poistoilmaliittäminen siirtäminen. Puhaltimen asento täyttyy vaihtaa ennen liittäntöjen asentamista.

ru - Перестановка воздуховода. Переналадка проводится перед монтажом.

el - Μετατόπιση σύνδεσης εξαγωγής αέρα. Η μετατροπή γίνεται πριν από την τοποθέτηση.

pt - Mudar o canhão de saída de ar. A alteração é efectuada antes da montagem.

tr - Hava Tahliye Bağlantısının Değiştirilmesi. Bu değişim montajdan önce yapılır.

sv - Flytta frånluftsanslutningen. Ommonteringen görs innan själva grundmonteringen.

no - Flytting av utluftningstilkoblingen. Ombyggingen må gjøres før montering.

pl - Przekładanie przyłącza wylotowego. Przebudowa odbywa się przed montażem.



